



60 LITRE WATER BLADDER

Thank you for your purchase of the Drifta Stockton 60 Litre Water Bladder.
. Please follow the instructions below to assemble your bladder to get the best use from it.

1. Fit 2 white bungs to the inlet and breather connections (see picture below). Ensure they are tight enough to seal, but do not overtighten.
2. Fit an L shaped spigot to the outlet. **The use of thread tape is recommended** (not supplied) to ensure a leak proof connection.
3. Next connect the hose to the L shaped spigot (heating the end of hose in hot water to soften it makes this easier) and use a hose clamp around the spigot and hose to create a secure connection.
4. Now put another hose clamp over the hose and then fit the red handled tap to the hose. Tighten the hose clamp around the connection.
5. You are now ready to use your water bladder.

To fill the bladder, open the inlet and insert a hose. Alternatively you can connect a hose to the spigot on the tap and bottom fill the bladder. If needed you can open the breather to allow air out as you fill, but be careful to avoid spills once the bladder reaches full. We supply additional fittings in case you would like to add a breather hose (you will need to source your own food grade hose if you wish to do this). This will allow you to have the breather hose overflow outside the vehicle when filling.

To use the bladder, simply ensure the tap is lower than the outlet and open the tap to let water flow out. There is no need to open the breather when dispensing water as the bladder will deflate as the water is used.

If storing the bladder, we recommend that you drain the bladder and allow it to dry out by opening all of the openings.

