

How to cook rice with Uniflame rice cooker DX

- 1) Wash the rice and adjust the water to the scale (Leave the rice in water approx.. for 30 minutes before heating, the rice will taste better this way)
- 2) Put the lid and start heating (with high heat at the beginning)
- 3) When the cooker starts steaming and the lid starts moving, lower the heat
- 4) When the lid stops moving and it does not steam anymore, turn off the heat and leave it for 5 minutes

Handling instruction

1. Before usage
 - Please wash the cooker before using it
2. To use the cooker for a longer time
 - Please do not keep the food inside the cooker for a long time
 - Please avoid cooking acid foods (such as vinegar, baking soda) and alkalinity food if possible
 - The inner surface of this cooker is fluorine-coated. Please use wooden or plastic kitchen tool so that they do not damage the surface.
3. For your own safety
 - The handle sometimes gets hot. Please be careful when you hold it
 - Please do not cook the rice with the water full in the cooker
4. Maintenance
 - Please do not use steel scrub brush or polishing powder
 - Please do not use the knife to scrape the burnt